Original	Rechange
Power Receiver	Power
Display	Display / Media
DVD / BD	Shift + 2
CBL/SAT	Shift + 0
VCR / DVR	Shift + 4
Game	Shift + 9
PC	Shift + Fav / Marker / PC
AUX	Shift + 7
FM	Shift + 6
TV / CD	Shift + 1
TV / CD	Shift + 3
NET	Shift + 5
USB	Shift + 8
Muting Receiver	Mute / Dimmer
Power Tv	Shift + Power
Vol + Tv	Shift + Vol +
CH/Disc/Album+ Receiver	CH+ / Page+

Original	Rechange
CH+ Tv	Shift + CH+ /
Vol + Receiver	Vol +
Input Tv	Shift + AV / Input / RDS
Vol - Tv	Shift + Vol -
CH/Disc/Album- Receiver	CH- / Page-
CH- Tv	Shift + CH- /
Vol - Receiver	Vol -
Guide/Top Menu	Shift + D.Menu / Top Menu
Up Receiver	Up
Up Tv	Shift + Up
Menu/Prev CH	Shift + Menu /
Left Receiver	Left
Left Tv	Shift + Left
Enter Receiver	OK
Enter Tv	Shift + OK
Right Receiver	Right
Right Tv	Shift + Right

Original	Rechange
Setup Receiver	Setup / OPT /
Setup Tv	Shift + Setup / OPT / Tools
Down Receiver	Down
Down Tv	Shift + Down
Return Receiver	Back / Return
Return Tv	Shift + Back / Return
Audio/Home	Menu / Home
Audio/Home	Audio / Lang I/II
I<< Receiver	I<< / Preset-
<< Receiver	<< / Tune-
>> Receiver	>> / Tune+
>>I Receiver	>>I / Preset+
Pause/Play reverse Receiver	Pause / Step / Freeze
Play Receiver	Play / Slow
Stop Receiver	Stop / Hold
Movie Tv/Search Receiver	Red / Netflix / Search
Movie/TV/Search	Shift + Red / Netflix / Search

Original	Rechange
Music/Repeat Receiver	Green / APP / Repeat
Music/Repeat	Shift + Green / APP /
Game/Random Receiver	Yellow / YouTube / Repeat
Game/Random	Shift + Yellow / YouTube /
THX/Play Mode Receiver	Blue / Prime Video / Random
Stereo/Play Mode	Shift + Blue / Prime
1 Receiver	1
2 Receiver	2
3 Receiver	3
4 Receiver	4
5 Receiver	5
6 Receiver	6
7 Receiver	7
8 Receiver	8
9 Receiver	9
+10/---/---10/Dimer/D.Tun Receive	Guide / EPG / -/--
0/11 Receiver	0

Original	Rechange	Original	Rechange
CLR/ Sl eep/ 12 Recei ver	Sl eep / Ti mer		
CLR/ Sl eep/ 12	Shi ft + Sl eep / Ti mer		

Original		Rechange	
SOURCE	Power BD/DVD		Power
SOURCE	Power CBL/SAT	SHIFT +	Shift + Power
BD/DVD	DVD/BD	LIST SMART	Smart / List
CBL/SAT	CBL/SAT	SHIFT + LIST SMART	Shift + Smart / List
CH DISC	CH Disc/Album+ CBL/SAT	SHIFT + CH PAGE	Shift + CH+ /
VOL	Vol + Receiver	VOL	Vol +
ALBUM	CH Disc/Album- CBL/SAT	SHIFT + CH PAGE	Shift + CH- /
VOL	Vol - Receiver	VOL	Vol -
TOP MENU GUIDE	Top Menu/Guide BD/DVD	TOP MENU D.MENU	D. Menu / Top
TOP MENU GUIDE	Top Menu/Guide CBL/SAT	SHIFT + TOP MENU D.MENU	Shift + D. Menu / Top Menu
	Up BD/DVD		Up
	Up CBL/SAT	SHIFT +	Shift + Up
MENU PREV CH	Menu/Prev CH	HOME MENU	Menu / Home
MENU PREV CH	Menu/Prev CH CBL/SAT	SHIFT + HOME MENU	Shift + Menu /
PLAYLIST	Left BD/DVD		Left
PLAYLIST	Left CBL/SAT	SHIFT +	Shift + Left
ENTER	Enter BD/DVD	OK	OK

Original		Rechange	
ENTER	Enter CBL/SAT	SHIFT + OK	Shift + OK
PLAYLIST	Right BD/DVD		Right
PLAYLIST	Right CBL/SAT	SHIFT +	Shift + Right
Q SETUP	Setup BD/DVD	OPT-TOOLS SETUP	Setup / OPT /
Q SETUP	Setup CBL/SAT	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Down BD/DVD		Down
	Down CBL/SAT	SHIFT +	Shift + Down
RETURN	Return BD/DVD	RETURN BACK	Back / Return
RETURN	Return CBL/SAT	SHIFT + RETURN BACK	Shift + Back / Return
AUDIO HOME	Home/Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<< BD/DVD	PRESET-	I<< / Preset-
	<< BD/DVD	TUNE-	<< / Tune-
	<< CBL/SAT	SHIFT + TUNE-	Shift + << /
	>> BD/DVD	TUNE+	>> / Tune+
	>> CBL/SAT	SHIFT + TUNE+	Shift + >> /
	>>I BD/DVD	PRESET+	>>I / Preset+
	Pause/Play rev. BD/DVD	STEP-FREEZE	Pause / Step / Freeze

Original	Rechange
Pause/Play rev. CBL/SAT	SHIFT + STEP-FREEZE Shift + Pause / Step /
Play BD/DVD	SLOW Play / Slow
Play CBL/SAT	SHIFT + SLOW Shift + Play /
Stop BD/DVD	HOLD Stop / Hold
Stop CBL/SAT	SHIFT + HOLD Shift + Stop /
SEARCH MOVIE/TV A Movie Tv/Search BD/DVD	NETFLIX SEARCH Red / Netflix / Search
SEARCH MOVIE/TV A Movie Tv/Search CBL/SAT	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /
REPEAT MUSIC B Music/Repeat	APP REPEAT Green / APP / Repeat
REPEAT MUSIC B Music/Repeat CBL/SAT	SHIFT + APP REPEAT Shift + Green / APP /
RANDOM GAME C Game/Random	YouTube REPEAT A-B Yellow / YouTube / Repeat
RANDOM GAME C Game/Random	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /
MODE THX D Stereo/Play Mode BD/DVD	Prime Video RANDOM Blue / Prime Video / Random
MODE THX D Stereo/Play Mode CBL/SAT	SHIFT + Prime Video RANDOM Shift + Blue / Prime
1 BD/DVD	TV 1 1
1 CBL/SAT	SHIFT + TV 1 Shift + 1
2 BD/DVD	DVD 2 2
2 CBL/SAT	SHIFT + DVD 2 Shift + 2

Original	Rechange
3 BD/DVD	CD-STB 3 3
3 CBL/SAT	SHIFT + CD-STB 3 Shift + 3
4 BD/DVD	VIDEO 4 4
4 CBL/SAT	SHIFT + VIDEO 4 Shift + 4
5 BD/DVD	TAPE 5 5
5 CBL/SAT	SHIFT + TAPE 5 Shift + 5
6 BD/DVD	TUNER 6 6
6 CBL/SAT	SHIFT + TUNER 6 Shift + 6
7 BD/DVD	AUX-HDD 7 7
7 CBL/SAT	SHIFT + AUX-HDD 7 Shift + 7
8 BD/DVD	USB 8 8
8 CBL/SAT	SHIFT + USB 8 Shift + 8
9 BD/DVD	BLUETOOTH 9 9
9 CBL/SAT	SHIFT + BLUETOOTH 9 Shift + 9
+10/--/--10/D.Tun Dimmer BD/DVD	-/-- GUIDE EPG Guide / EPG / -/--
0/11 BD/DVD	HDMI-SAT 0 0
0/11 CBL/SAT	SHIFT + HDMI-SAT 0 Shift + 0

Original	Rechange	Original	Rechange
CLR/ Sl eep/ 12	Sl eep / Ti mer		

Original		Rechange	
SOURCE	Power CD		Power
TV/CD	TV/CD	LIST SMART	Smart / List
CH DISC	CH/Disc+ CD	CH PAGE	CH+ / Page+
VOL	Vol + Receiver	VOL	Vol +
ALBUM	CH/Disc- CD	CH PAGE	CH- / Page-
VOL	Vol - Receiver	VOL	Vol -
	Up CD		Up
PLAYLIST	Left CD		Left
ENTER	Enter CD	OK	OK
PLAYLIST	Right CD		Right
SETUP	Setup CD	OPT-TOOLS SETUP	Setup / OPT /
	Down CD		Down
RETURN	Return CD	RETURN BACK	Back / Return
AUDIO HOME	Home/Audio CD	LANG I/II AUDIO	Audio / Lang I/II
	I<< CD	PRESET-	I<< / Preset-
	<< CD	TUNE-	<< / Tune-
	>> CD	TUNE+	>> / Tune+

Original		Rechange	
	>>I CD	PRESET+	>>I / Preset+
	Pause CD	STEP-FREEZE	Pause / Step / Freeze
	Play CD	SLOW	Play / Slow
	Stop CD	HOLD	Stop / Hold
SEARCH MOVIE/TV	Movie Tv/Search	NETFLIX SEARCH	Red / Netflix / Search
REPEAT MUSIC	Music/Repeat	APP REPEAT	Green / APP / Repeat
RANDOM GAME	Game/Random	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MODE THX	Stereo/Play Mode	Prime Video RANDOM	Blue / Prime Video / Random
1	1 CD	TV 1	1
2	2 CD	DVD 2	2
3	3 CD	CD-STB 3	3
4	4 CD	VIDEO 4	4
5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX-HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9

Original	Rechange	Original	Rechange
+10/ - - / - - 10/ D. Tu Di mmer CD	Gui de / EPG / - / - -		
0/ 11 CD	0		
CLR/ Sl eep/ 12	Sl eep / Ti mer		

Original		Rechange	
RECEIVER	Power Receiver Zone 2		Power
CH DISC	CH Disc/Album+ Zone 2	CH PAGE	CH+ / Page+
VOL	Vol + Zone 2	VOL	Vol +
ALBUM	CH Disc/Album Zone 2	CH PAGE	CH- / Page-
VOL	Vol - Zone 2	VOL	Vol -
	Up Zone 2		Up
PLAYLIST	Left Zone 2		Left
ENTER	Enter Zone 2	OK	OK
PLAYLIST	Right Zone 2		Right
SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /
	Down Zone 2		Down
RETURN	Return Zone 2	RETURN BACK	Back / Return
AUDIO HOME	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II
	<< Zone 2	PRESET-	<< / Preset-
	<< Zone 2	TUNE-	<< / Tune-
	>> Zone 2	TUNE+	>> / Tune+
	>>I Zone 2	PRESET+	>>I / Preset+

Original		Rechange	
	Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
	Play Zone 2	SLOW	Play / Slow
	Stop Zone 2	HOLD	Stop / Hold
SEARCH MOVIE/TV A	Movie Tv/Search Zone 2	NETFLIX SEARCH	Red / Netflix / Search
REPEAT MUSIC B	Music/Repeat	APP REPEAT	Green / APP / Repeat
RANDOM GAME C	Game/Random	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MODE THX D	Stereo/Play Mode Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Zone 2	TV 1	1
2	2 Zone 2	DVD 2	2
3	3 Zone 2	CD-STB 3	3
4	4 Zone 2	VIDEO 4	4
5	5 Zone 2	TAPE 5	5
6	6 Zone 2	TUNER 6	6
7	7 Zone 2	AUX-HDD 7	7
8	8 Zone 2	USB 8	8
9	9 Zone 2	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Rechange	
11 0	0/ 11 Zone 2	HDMI - SAT 0	0
12 CLR SLEEP	CLR/ Sl eep/ 12	TIMER SLEEP	Sl eep / Ti mer

Original	Rechange