Original		Rechange	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
OFF TIMER	Off Timer	TIMER SLEEP	Sleep / Timer
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
TV/AV	Tv/AV	RDS AV INPUT	AV / Input / RDS
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
TEXT	[≡]/Text	GOTO TEXT	Text / Goto

Original		Rechange	
F.P.	[≡♦]/F.P.	LIST SMART	Smart / List
INDEX	[≡i]/Index	MEDIA DISPLAY	Display / Media
HOLD	[≡+]/Hold	SHIFT + HOLD	Shift + Stop /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
C	C	RETURN BACK	Back / Return
0 VCR	0/VCR	HDMI-SAT 0	0
0 VCR	0/VCR	SHIFT + VIDEO 4	Shift + 4
i	i	ANGLE INFO	Info / Angle
∧	CH+	+ CH PAGE	CH+ / Page+

Original		Rechange	
+	Vol +	VOL +	Vol +
v	CH-	CH PAGE –	CH- / Page-
–	Vol -	VOL –	Vol -
ASPECT	[+] / Aspect	FORMAT PICTURE	Picture / Format
N	N	TOP MENU D.MENU	D. Menu / Top
⏻	Power VCR	SHIFT + ⏻	Shift + Power
REC ●	Rec VCR	REC MODE ●	Rec / Rec Mode
PROGR v	Programme Down	SHIFT + CH PAGE –	Shift + CH- /
RAMME ^	Programme Up	SHIFT + CH PAGE +	Shift + CH+ /
⏮ ◀◀	<< VCR	TUNE- ◀◀	<< / Tune-
⏭ ▶▶	>> VCR	TUNE+ ▶▶	>> / Tune+
■	Stop VCR	HOLD ■	Stop / Hold
II/▶	Pause/Step VCR	STEP-FREEZE II	Pause / Step / Freeze
▶	Play VCR	SLOW ▶	Play / Slow

Original	Rechange

Original	Rechange	Original	Rechange
Power DVD	Power		
Rec DVD	Rec / Rec Mode		
Programme Down	CH- / Page-		
Programme Up	CH+ / Page+		
I << DVD	I << / Preset-		
>>I DVD	>>I / Preset+		
Stop DVD	Stop / Hold		
Pause/Step DVD	Pause / Step / Freeze		
Play DVD	Play / Slow		