Original		Rechange	
	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
DVD/CD	Play DVD/CD	SLOW	Play / Slow
DISC PAUSE	Pause/Disc Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
SLOW/SE	<< Slow/Search	TUNE-	<< / Tune-
/SEARCH	Slow/Search >>	TUNE+	>> / Tune+
V/REW	I<<</Rew	PRESET-	I<< / Preset-
A/FF	>>I/FF	PRESET+	>>I / Preset+
SOUND	Sound	TITLE SOUND	Sound / Title
M.RE-MASTER	M. Re-master	LANG I/II AUDIO	Audio / Lang I/II
SUBWOOFER	Subwoofer	EQ SUBTITLE	Subtitle / EQ
SURROUND	Surround	SURROUND	Eject / Surround
GROUP	Group	FORMAT PICTURE	Picture / Format
A.ONLY	A. Only	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Rechange	
ALL DISC	All Disc	PROGRAM TV/ RADIO	TV/Radio /
TOP MENU DIRECT NAVIGATOR	Top Menu/Direct Navigator	TOP MENU D.MENU	D.Menu / Top
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
Q.REPLAY	Q Replay	GOTO TEXT	Text / Goto
TV/AV	Tv/AV	RDS AV INPUT	AV / Input / RDS
MENU PLAY LIST	Menu/Play List	HOME MENU	Menu / Home
	Up		Up
P.MEMORY	P. Memory	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
LUME	Vol +	VOL	Vol +
AUTO OFF	Auto Off	LIST SMART	Smart / List
TV CH A	Tv CH+	CH PAGE	CH+ / Page+

Original		Rechange	
VOL	Vol -	VOL –	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
V TV CH	Tv CH-	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
≧10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
PGM	PGM	PC FAV MARKER	Fav / Marker / PC
ANGLE/PAGE	Angle/Page	NETFLIX SEARCH	Red / Netflix / Search
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Rechange	
DISC	Disc	Prime Video RANDOM	Blue / Prime Video / Random
TV	Tv Power	SHIFT +	Shift + Power
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TAPE	<> Tape	SHIFT + STEP-FREEZE	Shift + Pause / Step /
PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PLAY/ REC	Play/Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
CLOCK/ TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
TV VOL +	Tv Vol +	SHIFT + + VOL	Shift + Vol +
– TV VOL	Tv Vol -	SHIFT + VOL –	Shift + Vol -
FL DISPLAY	FL Display	SHIFT + MEDIA DISPLAY	Shift + Display / Media
TUNER/ AUX	Tuner/AUX	SHIFT + TUNER 6	Shift + 6