Original		Rechange	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOL +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
AV	AV Tv	RDS AV INPUT	AV / Input / RDS
VOL −	Vol - Tv	SHIFT + VOL −	Shift + Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
VOL +	Vol +	VOL +	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
VOL −	Vol -	VOL −	Vol -
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Rechange	
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DVD	DVD	SHIFT + DVD 2	Shift + 2
iPod	iPod	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RADIO EXT-IN	Ext-In/Radio	APP REPEAT	Green / APP / Repeat
SEARCH	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
SEARCH	>>	TUNE+	>> / Tune+
SKIP	I<<	PRESET-	I<< / Preset-
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
SKIP	>>I	PRESET+	>>I / Preset+
MENU PLAY LIST	Menu/Play List	HOME MENU	Menu / Home
STOP	Stop	HOLD	Stop / Hold
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
START	Start	LIST SMART	Smart / List

Original		Rechange		Original	Rechange
	Up		Up		
	Top Menu/Direct Navigator		D. Menu / Top		
	Functions		Setup / OPT /		
	Left		Left		
	OK		OK		
	Right		Right		
	Play Mode/Repeat		Text / Goto		
	Down		Down		
	Return		Back / Return		
	Sound/CH		Audio / Lang I/II		
	Surround		Eject / Surround		
	W SRD		Zoom / Size		
	FL. Display		Info / Angle		