Original		Rechange	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
TV/AV	Tv/ AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOLUME	Vol + Tv	SHIFT + VOL	Shift + Vol +
DVD	DVD	SHIFT + DVD 2	Shift + 2
FM	FM	PROGRAM TV/ RADIO	TV/ Radio /
EXT-IN	EXT-IN	RDS AV INPUT	AV / Input / RDS
VOLUME	Vol - Tv	SHIFT + VOL	Shift + Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SELECT >	Select >	CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SELECT <	< Select	CH PAGE	CH- / Page-
7	7	AUX - HDD 7	7

Original		Rechange	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME	Vol +	VOL	Vol +
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
VOLUME	Vol -	VOL	Vol -
	I << Skip	PRESET-	I << / Preset-
	Skip >>I	PRESET+	>>I / Preset+
	<< Slow/Search	TUNE-	<< / Tune-
	Slow/Search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
QUICK OSD	Quick OSD	NETFLIX SEARCH	Red / Netflix / Search
VS	[I] VS	APP REPEAT	Green / APP / Repeat
ONE TOUCH PLAY	One Touch Play	PC FAV MARKER	Fav / Marker / PC

Original	Rechange
Top Menu/Direct Navigator	D.Menu / Top
Up	Up
Functions	Smart / List
◁ I / Left	Left
Enter	OK
Right / I ▷	Right
Menu/Play List	Menu / Home
Down	Down
Return	Back / Return
Level / Subwoofe	Sound / Title
EQ	Shift + Subtitle / EQ
H. Bass	Info / Angle
Group	Picture / Format
Audio	Audio / Lang I/II
Repeat	Shift + Green / APP /
Play Mode	Text / Goto
Quick Replay	Blue / Prime Video / Random

Original	Rechange
Zoom	Zoom / Size
Manual Skip	Yellow / YouTube / Repeat
Page/Angle	Shift + Setup / OPT / Tools
Subtitle	Subtitle / EQ
Setup	Setup / OPT /
Sleep	Sleep / Timer
FL. Display	Display / Media
Muting	Mute / Dimmer