Original		Rechange	
RECEIVER	Power Receiver		Power
BLU-RAY PLAYER	Power Blu-ray	SHIFT +	Shift + Power
BLU-RAY PLAYER	Bluray Player	HOME SMART	Smart
3	Source 3	A	Red
5	Source 5	B	Green
7	Source 7	C	Yellow
SETUP	Setup	SETTINGS OPT	Options
TUNER FM/AM	Tuner AM/FM	APP MEDIA	Media
BACK	Back	RETURN BACK	Back
INFO	[i]/Info	DISPLAY INFO	Info
	Up		Up
	Down		Down
	Right/>>		Right
	<<Left		Left
OK	OK	OK	Ok
	Stop		Stop
	Play	PLAY MODE	Play

Original		Rechange	
	Pause		Pause
	<<		<<
	>>		>>
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
+ TUNER PRESET	Tuner/Preset +	+ CH	Ch +
TUNER PRESET −	Tuner/Preset -	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Rechange	
0	0	0	0
SURROUND	Surround	SOUND DUAL	Dual
TONE	Tone	FAV PRE-CH	Pre Ch
MEMORY PROGRAM	Memory	TOP MENU MENU	Menu
CLEAR	Clear	CLEAR EXIT	Exit
FM MODE	FM Mode	SEARCH TV/R	TV/R
TEST TONE	Test Tone	REPEAT TEXT	Text

Original	Rechange