# Mandis shop

CU-MJ001

| Original | Rechange |
|---|---|
| Power | Power |
| Function | Menu / Home |
| Volume- | Vol - |
| Volume+ | Vol + |
| Flat | Sound / Title |
| Surr & ST Wide | Audio / Lang I/II |
| Smart EQ | Subtitle / EQ |
| Effect On/Off | Picture / Format |
| FM Mono | Red / Netflix / Search |
| Station Up | CH+ / Page+ |
| GEQ On/Off | Eject / Surround |
| Station Down | CH- / Page- |
| Random CD | Blue / Prime Video / Random |
| Pause CD | Pause / Step / Freeze |
| Play CD | Play / Slow |
| PGM CD | TV/Radio / |
| Sleep | Sleep / Timer |

| Original | Rechange |
|---|---|
| Wake Up | Back / Return |
| Snooze | Info / Angle |
| Deck I > | Right |
| < Deck I | Left |
| >> Deck I | Up |
| << Deck I | Down |
| Stop Deck I | OK |
| Rec Deck II | Rec / Rec Mode |
| Deck II > | Shift + Right |
| < Deck II | Shift + Left |
| << Deck II | Shift + Down |
| >> Deck II | Shift + Up |
| Stop Deck II | Shift + OK |
| Pause Deck II | Shift + Pause / Step / |
| Stop CD | Stop / Hold |
| Disc CD | Yellow / YouTube / Repeat |
| I << CD | I << / Preset- |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| >>I CD | PRESET+ >>I / Preset + | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |