| Original | | Rechange | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| INFO | Info | ANGLE INFO | Info / Angle |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| ⏮ | I<< | PRESET- ⏮ | I<< / Preset- |
| ▶ | Play | SLOW ▶ | Play / Slow |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ |
| ⏸ | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| MENU | Menu | HOME MENU | Menu / Home |
| CH+ ▲ | Up | | Up |
| CH+ ▲ | CH+ | + CH PAGE | CH+ / Page+ |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| VOL- ◀ | Vol - | VOL − | Vol - |
| VOL- ◀ | Left | ◀ | Left |
| OK | OK | OK | OK |

| Original | | Rechange | |
|---|---|---|---|
| VOL+ ▶ | Right | ▶ | Right |
| VOL+ ▶ | Vol + | + VOL | Vol + |
| RECORD | Record | REC MODE | Rec / Rec Mode |
| CH- ▼ | CH- | CH PAGE − | CH- / Page- |
| CH- ▼ | Down | ▼ | Down |
| ■ | Stop | HOLD ■ | Stop / Hold |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| EPG | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| BACK | Back | RETURN BACK | Back / Return |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| MEDIA | Media | MEDIA DISPLAY | Display / Media | | |
| USB | USB | SHIFT + USB 8 | Shift + 8 | | |
| TV/RADIO | Tv/Radio | PROGRAM TV/RADIO | TV/Radio / | | |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II | | |
| TTX | TTX | GOTO TEXT | Text / Goto | | |
| TIMER | Timer | TIMER SLEEP | Sleep / Timer | | |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC | | |
| RES | Res | LIST SMART | Smart / List | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| INFO | Info | ANGLE INFO | Info / Angle |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| ⏮ | I<< | PRESET- ⏮ | I<< / Preset- |
| ▶ | Play | SLOW ▶ | Play / Slow |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ |
| ⏸ | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| MENU | Menu | HOME MENU | Menu / Home |
| CH+ ▲ | Up / CH+ | + CH PAGE | CH+ / Page+ |
| CH+ ▲ | Up / CH+ | ▲ | Up |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| VOL- ◀ | Left / Vol - | VOL − | Vol - |
| VOL- ◀ | Left / Vol - | ◀ | Left |
| OK | OK | OK | OK |

| Original | | Rechange | |
|---|---|---|---|
| VOL+ ▶ | Right / Vol + | + VOL | Vol + |
| VOL+ ▶ | Right / Vol + | ▶ | Right |
| RECORD | Record | REC MODE | Rec / Rec Mode |
| CH- ▼ | Down / CH- | ▼ | Down |
| CH- ▼ | Down / CH- | CH PAGE − | CH- / Page- |
| ■ | Stop | HOLD ■ | Stop / Hold |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| EPG | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| BACK | Back | RETURN BACK | Back / Return |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| MEDIA | Media | MEDIA DISPLAY | Display / Media | | |
| USB | USB | SHIFT + USB 8 | Shift + 8 | | |
| TV/RADIO | TV / Radio | PROGRAM TV/RADIO | TV/Radio / | | |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II | | |
| TTX | TTX | GOTO TEXT | Text / Goto | | |
| TIMER | Timer | TIMER SLEEP | Sleep / Timer | | |
| FAV | Fav | PC FAV MARKER | Fav / Marker / PC | | |
| RES | Res. | LIST SMART | Smart / List | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |