Original		Rechange	
TV	Power TV		Power
STB	Power STB	SHIFT +	Shift + Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Rechange	
MUTE	Mute	MUTE	Mute
CH LIST	CH. List	DISC NAV LIST	List
P	PR+	+ CH	Ch +
P	PR-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
SMART HUB	Smart Hub	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
Enter		OK	Ok
A	Red	A	Red

Original		Rechange	
B	Green	B	Green
C	Yellow	C	Yellow
D	Blue	D	Blue
	Ball	APP MEDIA	Media
SEARCH	Search	SEARCH TV/R	TV/R
KEYPAD	Keypad	ECO 3D	3D
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu
P.SIZE	P. Size	PICTURE FORMAT	Format
AD/SUBT.	AD/Subt.	AD SUBT	Subt
<<| <<		<<	<<
Pause		Pause	Pause
>>| >>		>>	>>
Rec		REC MODE	Rec
Play		PLAY MODE	Play
Stop		Stop	Stop

Original	Rechange