Original		Rechange	
	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
–	--	SIZE ZOOM	Zoom / Size
PRE-CH	PRE-CH	PC FAV MARKER	Fav / Marker / PC
VOL +	Vol +	VOL +	Vol +
VOL –	Vol -	VOL –	Vol -

Original		Rechange	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH LIST	CH List	SHIFT + LIST SMART	Shift + Smart / List
	Smart Hub	LIST SMART	Smart / List
MENU	Menu	HOME MENU	Menu / Home
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
INFO	Info	ANGLE INFO	Info / Angle
RETURN	Return	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
	Enter	OK	OK
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
A	Red	NETFLIX SEARCH	Red / Netflix / Search
B	Green	APP REPEAT	Green / APP / Repeat
C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original	Rechange	Original	Rechange
D Blue	Prime Video / RANDOM Blue / Prime Video / Random		
Family Story Family Story	GOTO TEXT Text / Goto		
SEARCH Search	SHIFT + NETFLIX / SEARCH Shift + Red / Netflix /		
MTS MTS	EQ SUBTITLE Subtitle / EQ		
P.SIZE P. Size	FORMAT PICTURE Picture / Format		
SUPPORT Support	LANG I/II AUDIO Audio / Lang I/II		
CC CC	PROGRAM TV/RADIO TV/Radio /		
<< <<	TUNE- << / Tune-		
Pause	STEP-FREEZE Pause / Step / Freeze		
>> >>	TUNE+ >> / Tune+		
Rec	REC MODE Rec / Rec Mode		
Play	SLOW Play / Slow		
Stop	HOLD Stop / Hold		
CH CH+	CH PAGE CH+ / Page+		
CH CH-	CH PAGE CH- / Page-		