Mandis shop

Samsung DJ 9600114S

Original		Rechange		Original	Rechange
Power	Power		Power		
Auto	Auto	TV 1	1		
Recharging	Recharging	LIST SMART	Smart / List		
Spot	Spot	DVD 2	2		
Max	Max	CD - STB 3	3		
Start/ Stop	Start/Stop	OK	OK		
	Up		Up		
	Right		Right		
	Left		Left		
Manual	Manual	VIDEO 4	4		
Edge	Edge	TUNER 6	6		
Clock	Clock	HOME MENU	Menu / Home		
Turbo	Turbo	TAPE 5	5		
Timer/Daily	Timer/Daily	TIMER SLEEP	Sleep / Timer		
	Nothing	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

https://mandis-shop.com/fr/Samsung/1068349-telecommande-de-remplacement-pour-Samsung-DJ9600114S.html