Original	Rechange	Original	Rechange
Power	Power	DVD Setup	Setup / OPT /
Muting	Mute / Dimmer	Name	Text / Goto
Play	Play / Slow	AMP Menu	Menu / Home
Pause	Pause / Step / Freeze	Up	Up
Stop	Stop / Hold	Angle	Info / Angle
<</ ◁ Slow/ Tunin	<< / Tune-	Left	Left
Tuning+/ Slow	>> / Tune+	Enter	OK
I <</ Preset-	I << / Preset-	Right	Right
>>I / Preset+	>>I / Preset+	Clear	Exit / Cancel / Clear
Bass Level	Sound / Title	Down	Down
Audio	Audio / Lang I/II	Return	Back / Return
Subtitle	Subtitle / EQ	Vol +	Vol +
Open/ Close	Eject / Surround	Memory	Smart / List
Band	Picture / Format	Vol -	Vol -
Sleep	Sleep / Timer	Display	Display / Media
Tv/ Video	TV/ Radio /	1	1
DVD Menu	D. Menu / Top Menu	2	2

Original		Rechange	
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
>10	>10	GUIDE EPG	Guide / EPG / -/--
10/0 0	0	0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PLAY MODE	Play Mode	SHIFT + SLOW ▶	Shift + Play /
STEREO/MONO	Stereo/Mono	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
FUNCTION	Function	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
DVD TOP MENU	DVD Top Menu	SHIFT + HOME MENU	Shift + Menu /
SOUND FIELD +	Sound Field+	SHIFT + VOL +	Shift + Vol +
NIGHT MODE	Night Mode	SHIFT + LIST SMART	Shift + Smart / List
Sound Field-		SHIFT + VOL −	Shift + Vol -

Original		Rechange	
ENTER	Enter1	SHIFT + TV 1	Shift + 1
DVD DISPLAY	DVD Display	SHIFT + DVD 2	Shift + 2

Original		Rechange		Original	Rechange
TV I/⏻	Power Tv		Power		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
>10	0/ 10	HDMI - SAT 0	0		
>10	- / - -	GUIDE EPG	Gui de / EPG / - / - -		
ENTER	Ent er	OK	OK		
TV VOL +	Tv Vol +	+ VOL	Vol +		
TV CH +	Tv CH+	+ CH PAGE	CH+ / Page+		
VOL -	Tv Vol -	VOL −	Vol -		
CH -	Tv CH-	CH PAGE −	CH- / Page-		