Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	Yellow / Play	Play / Slow
Power	Power	Yellow / Play	Yellow / YouTube / Repeat
1	1	Blue / >>	>> / Tune+
2	2	Blue / >>	Blue / Prime Video / Random
3	3	Up	Up
4	4	Left	Left
5	5	OK	OK
6	6	Right	Right
7	7	Down	Down
8	8	SFI	D.Menu / Top
9	9	Exit / Recall	Back / Return
✓	Guide / EPG / -/--	Exit / Recall	Exit / Cancel / Clear
0	0	Info	Info / Angle
Red / <<	Red / Netflix / Search	Prog +	CH+ / Page+
Red / <<	<< / Tune-	TV / Radio	TV/Radio /
Green / Stop	Green / APP / Repeat	Vol +	Vol +
Green / Stop	Stop / Hold	Prog -	CH- / Page-

Original	Rechange	Original	Rechange
MENU Menu	HOME MENU Menu / Home		
Vol -	VOL Vol -		
TV/SAT TV/SAT	LIST SMART Smart / List		
TXT TXT	GOTO TEXT Text / Goto		
STOP Stop	STEP-FREEZE Pause / Step / Freeze		
EXT EXT	MEDIA DISPLAY Display / Media		
SAT1 SAT1 + OK	SHIFT + DVD 2 Shift + 2		
SAT2 SAT2 + OK	SHIFT + CD-STB 3 Shift + 3		
TV TV + OK	SHIFT + TV 1 Shift + 1		
PIP	FORMAT PICTURE Picture / Format		

Original	Rechange
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
✓	Guide / EPG / -/--
0	0
A/B	Shift + Yellow / YouTube /
Red / <<	<< / Tune-
Red / <<	Red / Netflix / Search
Green / Stop	Green / APP / Repeat

Original	Rechange
Green / Stop	Stop / Hold
Yellow / Play	Play / Slow
Yellow / Play	Yellow / YouTube / Repeat
Blue / >>	>> / Tune+
Blue / >>	Blue / Prime Video / Random
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
SFI	D.Menu / Top
Exit / Recall	Exit / Cancel / Clear
Exit / Recall	Back / Return
Info	Info / Angle
Prog +	CH+ / Page+
TV / Radio	TV/Radio /
Vol +	Vol +

Original	Rechange	Original	Rechange
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + 2		
SAT2 + OK	SHIFT + 3		
TV + OK	SHIFT + 1		

Original	Rechange
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
✓	Guide / EPG / -/--
0	0
A/B	SHIFT + Yellow / YouTube /
Red / <<	Red / Netflix / Search
Red / <<	<< / Tune-
Green / Stop	Stop / Hold

Original	Rechange
Green / Stop	Green / APP / Repeat
Yellow / Play	Play / Slow
Yellow / Play	Yellow / YouTube / Repeat
Blue / >>	>> / Tune+
Blue / >>	Blue / Prime Video / Random
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
SFI	D.Menu / Top
Exit / Recall	Back / Return
Exit / Recall	Exit / Cancel / Clear
Info	Info / Angle
Prog +	CH+ / Page+
TV / Radio	TV/ Radio /
Vol +	Vol +

Original	Rechange	Original	Rechange
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + 2		
SAT2 + OK	SHIFT + 3		
TV + OK	SHIFT + 1		