Original		Rechange	
	Source	RDS AV INPUT	AV / Input / RDS
	Power		Power
LIST	List	LIST SMART	Smart / List
	[< >]	FORMAT PICTURE	Picture / Format
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
	O)I/II	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AD	AD	TITLE SOUND	Sound / Title
0	0	HDMI - SAT 0	0

Original		Rechange	
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
TV	TV	SHIFT + TV 1	Shift + 1
+	Vol +	+ VOL	Vol +
	[i+]/[i≡]	ANGLE INFO	Info / Angle
P	PR+	+ CH PAGE	CH+ / Page+
–	Vol -	VOL –	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
P	PR-	CH PAGE –	CH- / Page-
QUICK	Quick	MEDIA DISPLAY	Display / Media
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down

Original	Rechange	Original	Rechange
Exit	Exit / Cancel / Clear		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Text	Text / Goto		
Stop	Stop / Hold		
Play	Play / Slow		
Pause/ Step/ [▼]	Pause / Step / Freeze		
I <<</ [≡?]	I << / Preset-		
<<</ [≡+]	<< / Tune-		
>>/ [≡♦]	>> / Tune+		
>>I / [O] / [≡x]	>>I / Preset +		