Original		Rechange	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Recall	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
	Source	RDS AV INPUT	AV / Input / RDS
+	Vol +	+ VOL	Vol +
CONTENT MENU A/D	A/D/Content Menu	LIST SMART	Smart / List
P	P+	+ CH PAGE	CH+ / Page+
−	Vol -	VOL −	Vol -

Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
P	P-	CH PAGE −	CH- / Page-
DVD MENU MENU	Menu/DVD	HOME MENU	Menu / Home
RETURN EXIT	Exit/Return	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
TOP MENU GUIDE	Guide/Top	-/-- GUIDE EPG	Guide / EPG / -/--
	Down		Down
SET UP TV/FAV RADIO	Tv/FAV/Radio/Set	PROGRAM TV/ RADIO	TV/Radio /
SET UP TV/FAV RADIO	Tv/FAV/Radio/Set	PC FAV MARKER	Fav / Marker / PC
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	[<>]	FORMAT PICTURE	Picture / Format

Original	Rechange	Original	Rechange
←[/]→	Display / Media		
[i +] / [≡i]	Info / Angle		
Text	Text / Goto		
Audio	Audio / Lang I/II		
Subtitle	Subtitle / EQ		
Eject	Eject / Surround		
O) I / II	Shift + Audio / Lang I/II		
Stop	Stop / Hold		
Play/ [≡o]	Play / Slow		
II / II >/ [▼]	Pause / Step / Freeze		
I <</ [≡?]	I << / Preset-		
<</ [≡+]	<< / Tune-		
>>/ [≡♦]	>> / Tune+		
>>I / [O] / [≡X]	>>I / Preset+		

Original	Rechange	Original	Rechange
Power	Power	Up	Up
1	1	Left	Left
2	2	OK	OK
3	3	Right	Right
4	4	Guide/ Top	D. Menu / Top
5	5	Down	Down
6	6	Tv/ FAV/ Radio/ Set	Setup / OPT /
7	7	[<>]	Picture / Format
8	8	←[/] →	Display / Media
9	9	[i +] / [≡i]	Info / Angle
0	0	Text	Text / Goto
Source	AV / Input / RDS	Audio	Audio / Lang I/II
Vol +	Vol +	Subtitle	Subtitle / EQ
Vol -	Vol -	Eject	Eject / Surround
Mute	Mute / Dimmer	O) I / II	Shift + Audio / Lang I/II
Menu/ DVD	Menu / Home	Stop	Stop / Hold
Exit/ Return	Back / Return	Play/ [≡o]	Play / Slow

Original	Rechange	Original	Rechange
I I / I I >/ [▼]	Pause / Step / Freeze		
I <</ [≡?]	I << / Preset-		
<</ [≡+]	<< / Tune-		
>>/ [≡♦]	>> / Tune+		
>>I / [O] / [≡X]	>>I / Preset +		

Original	Rechange	Original	Rechange
Power	Power	Mute	Mute / Dimmer
1	1	P-	CH- / Page-
2	2	Menu/ DVD	Menu / Home
3	3	Exit / Return	Shift + Back / Return
4	4	Exit / Return	Exit / Cancel / Clear
5	5	Up	Up
6	6	Left	Left
7	7	OK	OK
8	8	Right	Right
9	9	Guide/ Top	D. Menu / Top
Recall	Back / Return	Down	Down
0	0	Tv/ FAV/ Radio/ Set	TV/ Radio /
Source	AV / Input / RDS	Tv/ FAV/ Radio/ Set	Setup / OPT /
Vol +	Vol +	Red	Red / Netflix / Search
A/D / Content	Smart / List	Green	Green / APP / Repeat
P+	CH+ / Page+	Yellow	Yellow / YouTube / Repeat
Vol -	Vol -	Blue	Blue / Prime Video / Random

Original	Rechange	Original	Rechange
[<>]	Picture / Format		
←[/]→	Display / Media		
[i+] / [≡i]	Info / Angle		
Text	Text / Goto		
Audio	Audio / Lang I/II		
Subtitle	Subtitle / EQ		
Eject	Eject / Surround		
O) I / II	Shift + Audio / Lang I/II		
Stop	Stop / Hold		
Play/ [≡o]	Play / Slow		
II / II >/ [▼]	Pause / Step / Freeze		
I <</ [≡?]	I << / Preset-		
<</ [≡+]	<< / Tune-		
>>/ [≡♦]	>> / Tune+		
>>I / [O] / [≡X]	>>I / Preset+		