































































| Original | | Replacement | | Original | | Replacement | |
|---|-------|---|------------------|---|------------------|---|-----------------------------|
|  | Power |  | Power |  | Vol- |  | Vol- |
|  | 1 |  | 1 |  | OK |  | OK |
|  | 2 |  | 2 |  | Down |  | Down |
|  | 3 |  | 3 |  | P- |  | CH- / Page- |
|  | 4 |  | 4 |  | i |  | Info / Angle |
|  | 5 |  | 5 |  | Format / Picture |  | Picture / Format |
|  | 6 |  | 6 |  | TXT |  | Text / Goto |
|  | 7 |  | 7 |  | Mute |  | Mute / Dimmer |
|  | 8 |  | 8 |  | Red/AKT |  | Red / Netflix / Search |
|  | 9 |  | 9 |  | Green/Timer |  | Sleep / Timer |
|  | 0/AV |  | AV / Input / RDS |  | Green/Timer |  | Green / APP / Repeat |
|  | 0/AV |  | 0 |  | Yellow/[I] |  | Yellow / YouTube / Repeat |
|  | Up |  | Up |  | Blue/[++] |  | Blue / Prime Video / Random |
|  | P+ |  | CH+ / Page+ |  | -O |  | << / Tune- |
|  | Right |  | Right |  | O+ |  | >> / Tune+ |
|  | Vol+ |  | Vol+ |  | -* |  | I<< / Preset- |
|  | Left |  | Left |  | *+ |  | >>I / Preset+ |





| Original | Replacement | Original | Replacement |
|---|--|--|---|
|  Power |  Power |  Vol- |  Vol- |
|  1 |  1 |  OK |  OK |
|  2 |  2 |  P- |  CH- / Page- |
|  3 |  3 |  Down |  Down |
|  4 |  4 |  i |  Info / Angle |
|  5 |  5 |  Format / Picture |  Picture / Format |
|  6 |  6 |  TXT |  Text / Goto |
|  7 |  7 |  Mute |  Mute / Dimmer |
|  8 |  8 |  Red/AKT |  Red / Netflix / Search |
|  9 |  9 |  Green/Timer |  Green / APP / Repeat |
|  0/AV |  AV / Input / RDS |  Green/Timer |  Sleep / Timer |
|  0/AV |  0 |  Yellow/[I] |  Yellow / YouTube / Repeat |
|  P+ |  CH+ / Page+ |  Blue/[++] |  Blue / Prime Video / Random |
|  Up |  Up |  -O |  << / Tune- |
|  Right |  Right |  O+ |  >> / Tune+ |
|  Vol+ |  Vol+ |  -* |  I<< / Preset- |
|  Left |  Left |  *+ |  >>I / Preset+ |



