









Original	Replacement
 Mute	 Mute
 Power	 Power
 Subtitle	 Subt
 Language	 Dual
 Open / Close	 Eject
 Angle	 Format
 Prog	 Sleep
 Title	 List
 Menu	 Menu
 Vol +	 Vol +
 Vol -	 Vol -
 Setup	 Options
 Play / Pause	 Play
 Play / Pause	 Pause
 Up	 Up
 Down	 Down
 Right	 Right

Original	Replacement
 Left	 Left
 Enter	 Ok
 Stop	 Stop
 L / R	 3D
 1	 1
 2	 2
 Goto	 Media
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 10+	 Guide
 0	 0
 << Rev	 <<





Original	Replacement	Original	Replacement
FWD	>> Fwd	>>	>>
PREV	I<< Prev	<<	I<<
NEXT	>>I Next	>>I	>>I
DISPLAY	Display	INFO	Info
SLOW	Slow	SHIFT +  PLAY MODE	Shift + Play
STEP	Step	SHIFT +  PAUSE	Shift + Pause
PBC	PBC	HOME SMART	Smart
ZOOM	Zoom	SHIFT +  ZOOM	Shift + Eject
REPEAT	Repeat	REPEAT TEXT	Text
A - B	A - B	SHIFT +  REPEAT TEXT	Shift + Text
VIDEO MODE	Video / Mode	SEARCH TV/R	TV/R

