



Original	Replacement	Original	Replacement
 Power	 Power	 >>I	 >>I
 Function Tv	 AV	 <<	 <<
 Eject	 Eject	 >>	 >>
 Sleep	 Sleep	 Stop	 Stop
 1/RDS Display	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3/TA	 3	 Vol+	 Vol +
 4/PTY-	 4	 Vol-	 Vol -
 5/PTY Search	 5	 Mute	 Mute
 6/PTY+	 6	 Tuning/CH+	 Ch +
 7	 7	 Tuning/CH-	 Ch -
 8	 8	 SFE Mode	 Smart
 9	 9	 Disc Menu	 D. Menu
 0	 0	 Menu	 Menu
 Full Screen	 3D	 Title Menu/PopUp	 Media
 Repeat	 Text	 Tools	 Options
 I<<	 I<<	 Info	 Info





Original	Replacement	Original	Replacement
	Return		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Red		Red
	Green		Green
	Yellow/Tuner		Yellow
	Blue/Mo/ST		Blue
	PL II		Dual
	DSP		Guide

