










Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	TV/TXT		Text
	Cancel		Media
	Reveal		D. Menu
	Nicam/A2		Dual
	Size		Format
	Hold		Eject
	Index		TV/R
	Subpage		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Mute		Mute
	Menu		Menu
	Exit		Exit
	Vol+		Vol +
	Vol-		Vol -
	Channel List		Smart
	EPG		Guide
	Info		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5





Original	Replacement	Original	Replacement
 6	 6		 Play
 7	 7		 Pause
 8	 8		 Stop
 9	 9		 List
 0	 0		 Shift + Text
 FAV	 Pre Ch		
 Recall	 Back		
 Picture	 Shift + Format		
 Sound	 Shift + Dual		
 Sleep	 Sleep		
 Subtitle	 Subt		
 Rec	 Rec		
 Aspect	 3D		
 <<	 <<		
 >>	 >>		
 <<	 <<		
 >>	 >>		

