





Original	Replacement	Original	Replacement
Power	Power	Vol -	Vol -
Mute	Mute	Aide	Smart
1	1	CH -	Ch -
2	2	Up	Up
3	3	Left	Left
4	4	OK	Ok
5	5	Right	Right
6	6	Retour	Back
7	7	Down	Down
8	8	Menu	Menu
9	9	<<	<<
<->	Exit	Play / Pause	Play
0	0	Play / Pause	Pause
Recall	Pre Ch	Stop	Stop
Vol +	Vol +	>>	>>
Info	Info	Red	Red
CH +	Ch +	Green	Green





Original	Replacement	Original	Replacement
 Yellow	 Yellow		
 Blue	 Blue		

