



Original	Replacement
 Power	 Power
 Source	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 www. Browser	 Media
 Refresh	 Guide
 Home	 Smart
 TXT / Mix	 Text
 Stop	 Stop
 Subtitle	 Subt
 Audio	 Dual
 Screenshot	 Shift + Media
 << / Index	 Shift + Info
 << / Index	 <<
 >> / Hold	 Shift + Stop

Original	Replacement
 >> / Hold	 >>
 I<< / Reveal	 3D
 I<< / Reveal	 I<<
 >>I / Cancel	 Shift + Exit
 >>I / Cancel	 >>I
 Subpage	 Shift + Subt
 Aspect	 Format
 Freeze	 Shift + Pause
 FAV	 Pre Ch
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 Enter	 Ok
 Play/Pause / Size	 Eject





Original	Replacement
Play/Pause / Size	Play
Play/Pause / Size	Pause
Set	Options
Vol +	Vol +
Vol -	Vol -
Mute	Mute
TV / Radio	TV/R
CH +	Ch +
CH -	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

Original	Replacement
9	9
0	0
i / Display	Info
Recall / Mouse	Back
Sleep	Sleep
S-Mode	Shift + Dual
P-Mode	Shift + Format

