



| Original | Replacement | | |
|----------|--------------|--|-----------------------------|
| | Power | | Power |
| | Mute | | Mute / Dimmer |
| | Red / Media | | Red / Netflix / Search |
| | Red / Media | | Display / Media |
| | Green / TV | | Green / APP / Repeat |
| | Green / TV | | TV/Radio / |
| | Yellow / Web | | Yellow / YouTube / Repeat |
| | Blue / APP | | Blue / Prime Video / Random |
| | Blue / APP | | Smart / List |
| | Vol- | | Vol- |
| | I<< | | I<< / Preset- |
| | >>I | | >>I / Preset+ |
| | Vol+ | | Vol+ |
| | Home | | D.Menu / Top |
| | Up / CH+ | | CH+ / Page+ |
| | Up / CH+ | | Up |
| | Return | | Back / Return |

| Original | Replacement | | |
|----------|-------------|--|-------------------|
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Menu | | Menu / Home |
| | Down / CH- | | CH- / Page- |
| | Down / CH- | | Down |
| | Mouse | | Info / Angle |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 1/A/a | | Guide / EPG / -/- |





| Original | | Replacement | | Original | | Replacement | |
|----------|-----|-------------|-------------------|----------|--|-------------|--|
| | 0 | | 0 | | | | |
| | <x] | | Fav / Marker / PC | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | Replacement | | |
|----------|--------------|--|-----------------------------|
| | Power | | Power |
| | Mute | | Mute / Dimmer |
| | Red / Media | | Red / Netflix / Search |
| | Red / Media | | Display / Media |
| | Green / TV | | Green / APP / Repeat |
| | Green / TV | | TV/Radio / |
| | Yellow / Web | | Yellow / YouTube / Repeat |
| | Blue / APP | | Blue / Prime Video / Random |
| | Blue / APP | | Smart / List |
| | Vol- | | Vol- |
| | I<< | | I<< / Preset- |
| | >>I | | >>I / Preset+ |
| | Vol+ | | Vol+ |
| | Home | | D.Menu / Top |
| | Up / CH+ | | Up |
| | Up / CH+ | | CH+ / Page+ |
| | Return | | Back / Return |

| Original | Replacement | | |
|----------|-------------|--|-------------------|
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Menu | | Menu / Home |
| | Down / CH- | | Down |
| | Down / CH- | | CH- / Page- |
| | Mouse | | Info / Angle |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 1/A/a | | Guide / EPG / -/- |



