



















Original	Replacement	Original	Replacement
 Power	 Power	 Back / Del	 Back
 Mute	 Mute	 Up	 Up
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Menu	 Menu
 6	 6	 EPG	 Guide
 7	 7	 YouTube	 Media
 8	 8	 Vol +	 Vol +
 9	 9	 Vol -	 Vol -
 0	 0	 Home / Source	 AV
 Info	 Info	 Text	 Text
 Red	 Red	 P +	 Ch +
 Green	 Green	 P -	 Ch -
 Yellow	 Yellow	 List	 List
 Blue	 Blue	 Netflix	 Smart





Original		Replacement		Original	Replacement
	Play	 PLAY MODE	Play		
	Pause / [≡]		Pause		
	Stop / [≡[]]		Stop		
	[≡⇅]	 REC MODE	Rec		
	<< / [≡⊖]		<<		
	<< / [≡i]		<<		
	>> / [≡X]		>>		
	>> / [≡?]		>>		
	Exit	 CLEAR EXIT	Exit		

