






































































Original		Replacement		Original		Replacement	
	Power		Power		Rec		Rec
	Mute		Mute		<<		<<
	1		1		>>		>>
	2		2		I<< / ⏸		I<<
	3		3		>>I / ⏸		>>I
	4		4		Red		Red
	5		5		Green		Green
	6		6		Yellow		Yellow
	7		7		Blue		Blue
	8		8		Media		Media
	9		9		Guide		Guide
	0		0		Up		Up
	TV Portal		Smart		Left		Left
	Menu		Menu		OK		Ok
	Play		Play		Right		Right
	Pause		Pause		Down		Down
	Stop		Stop		Exit		Exit





Original	Replacement
Back	Back
Vol +	Vol +
Vol -	Vol -
List	List
i	Info
P+ / Page +	Ch +
P- / Page -	Ch -
OPT+	Options
Sound	Dual
SUB	Subt
TV / Radio	TV/R
Text	Text
+ Book	Shift + Pre Ch
Book	Pre Ch
I>	Shift + Right
Source	AV
Sleep	Sleep

Original	Replacement
V-Format	Format
Wide	3D

