







































































Original	Replacement	Original	Replacement
 Power	 Power	 Left	 Left
 Source	 AV	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Open / TV/Radio	 TV/R
 4	 4	 Open / TV/Radio	 Eject
 5	 5	 Exit / Title	 Exit
 6	 6	 EPG / D.Menu	 Guide
 7	 7	 EPG / D.Menu	 Shift + Menu
 8	 8	 Red / Goto	 Red
 9	 9	 Green / Angle	 Green
 0	 0	 Yellow / Repeat	 Yellow
 -/--	 Shift + Guide	 Blue / A-B	 Blue
 Recall	 Back	 Vol +	 Vol +
 Media	 Media	 Vol -	 Vol -
 Menu	 Menu	 Display	 Info
 Up	 Up	 Mute	 Mute





	Original	Replacement		Original	Replacement
	CH+	+ CH		Subtitle	AD SUBT
	CH -	- CH		S-Mode	SHIFT + SOUND DUAL
Repeat	Yellow / Repeat	SHIFT + REPEAT TEXT	Size / Zoom	Size / Zoom	SHIFT + ZOOM
Text	<< / Text	<<	P-Mode	P-Mode	SHIFT + PICTURE FORMAT
Text	<< / Text	REPEAT TEXT			
	Play / Pause	PLAY MODE ▶			
	Play / Pause				
Subpage	>> / Subpage	>>			
Fav	I<< / FAV	I<<			
Fav	I<< / FAV	FAV PRE-CH			
Index	>>I / Index	>>I			
Sleep	Sleep	PROG SLEEP			
D.SETUP	D.Setup	SETTINGS OPT			
	Stop	■			
Hold / Freeze	Hold / Freeze	SHIFT + ■			
Lang / Audio	Lang / Audio	SOUND DUAL			
Aspect	Aspect	PICTURE FORMAT			

