



Original	Replacement
 Power	 Power
 Source Search	 Source
 Computer	 Comp / Video
 Video	 Shift + Mode
 USB	 3D / Invert
 LAN	 Shift + Comp / Video
 MHL Menu	 Help / Info
 Page+	 Shift + Up
 Auto	 Auto
 Aspect	 Eco / Aspect
 Color Mode	 Mode
 ID	 Shift + Right
 Menu	 Menu
 Esc	 Shift + Power
 User	 Shift + Auto
 Pointer	 Volt / Focus
 Up	 Up

Original	Replacement
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Enter
 Page-	 Shift + Down
 E-Zoom+	 + / Play
 E-Zoom-	 - / Stop
 Vol+	 Vol + / Page +
 Vol-	 Vol - / Page -
 A/V Mute	 Blank / Mute
 Split	 Shift + Source
 Freeze	 Freeze / Timer
 Home	 Shift + Menu
 1	 Shift + Vol + / Page +
 2	 Shift + + / Play
 3	 Shift + Volt / Focus
 4	 Shift + Vol - / Page -





Original	Replacement	Original	Replacement
5	Shift + Stop Shift + - / Stop		
6	Shift + Info Shift + Help / Help /		
7	Shift + Aspect Shift + Eco / Aspect		
8	Shift + Invert Shift + 3D / 3D /		
9	Shift + Mute Shift + Blank / Mute		
0	Shift + Timer Shift + Freeze / Timer		

