



























































Original	Replacement	Original	Replacement
 Power	 Power	 D.Sub/Reveal	 Media
 Mute	 Mute	 D.Lan/Nicam/A2	 Dual
 Red/Title	 Red	 Tv/Radio	 TV/R
 Green/Goto	 Green	 FAV	 Pre Ch
 Yellow/Repeat	 Yellow	 Nothing	 Shift + Back
 Blue/A-B	 Blue	 Sleep	 Sleep
 <</Index	 <<	 Disp	 Info
 >>/Hold	 >>	 Input	 AV
 I<</Size	 I<<	 Menu	 Menu
 >>I/Subpage	 >>I	 Exit	 Exit
 Play	 Play	 Up	 Up
 Pause	 Pause	 Down	 Down
 Stop	 Stop	 Right	 Right
 Eject	 Eject	 Left	 Left
 Subtitle	 Subt	 OK	 Ok
 D.Set/Tv/TXT	 Text	 Vol+	 Vol +
 D.Menu/Cancel	 D. Menu	 Vol-	 Vol -





Original	Replacement
EPG	GUIDE
CH.L	LIST
CH+	Ch +
CH-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	SHIFT + -/-- GUIDE
Recall	BACK
Picture	FORMAT

Original	Replacement
ASPECT	ECO 3D
SOUND	SHIFT + SOUND DUAL

