

































Original		Replacement		Original	Replacement
	Power		Power		
	Source		AV		
	Bluetooth/Pair		Smart		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	Play		Play		
	Pause		Pause		
	Vol+		Vol +		
	Vol-		Vol -		
	Mute		Mute		
	Sound Mode		Dual		
	*		Menu		
	Woofer+		Ch +		
	Woofer-		Ch -		

