

















































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	Rec		Rec
	APP		Media
	<<		<<
	Play / Pause		Play
	Play / Pause		Pause
	>>		>>
	I<<		I<<
	Stop		Stop
	>>I		>>I
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Menu		Menu
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	EPG		Guide
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	Info		Info
	Mute		Mute
	Prog+		Ch +
	Prog-		Ch -
	1		1
	2		2
	3		3
	4		4





Original		Replacement		Original		Replacement	
	Power		Power		6		6
	APP		Media		7		7
	Menu		Menu		8		8
	Exit		Exit		9		9
	OK		Ok		0		0
	Back		Back		Text		Text
	Vol+		Vol +				
	Vol-		Vol -				
	Info		Info				
	Mute		Mute				
	Prog+		Ch +				
	Prog-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

