

























































































| Original   | Replacement  | Original   | Replacement   |
|--|--|--|---|
|  RCVR On                  |  Power          |  RCVR Test / Menu         |  Menu    |
|  RCVR Standby             |  Shift + Power  |  RCVR Audio               |  Dual    |
|  RCVR Sleep               |  Sleep          |  RCVR Level               |  Media   |
|  RCVR Return              |  Back           |  RCVR Level Up            |  Smart   |
|  RCVR Setup               |  Options        |  RCVR I<<                 |  I<<     |
|  RCVR Disc+               |  Ch +           |  RCVR Play                |  Play    |
|  RCVR Disc-               |  Ch -           |  RCVR >>I                 |  >>I     |
|  RCVR Up                  |  Up             |  RCVR <<                  |  <<      |
|  RCVR Left                |  Left           |  RCVR Stop                |  Stop    |
|  RCVR Enter               |  Ok             |  RCVR >>                  |  >>      |
|  RCVR Right              |  Right         |  RCVR Rec /              |  Rec    |
|  RCVR Down              |  Down         |  RCVR Pause / Play Rev. |  Pause |
|  RCVR Vol+              |  Vol +        |  Open / Close           |  Eject |
|  RCVR Vol-              |  Vol -        |  RCVR Input Sel.        |  1     |
|  RCVR Muting            |  Mute         |  RCVR Input Sel.        |  2     |
|  RCVR CH Sel / Top Menu |  Shift + Menu |  RCVR Input Sel.        |  3     |
|  RCVR CH Sel / Top Menu |  D. Menu      |  RCVR Input Sel.        |  4     |










































































| Original  | Replacement   |
|---|---|
|  RCVR Input Sel. |  5   |
|  RCVR Input Sel. |  6   |
|  RCVR Input Sel. |  7   |
|  RCVR Input Sel. |  8   |
|  RCVR Input Sel. |  9   |
|  RCVR Input Sel. |  0   |
|  RCVR Stereo     |  +  Shift + 1     |
|  RCVR Direct     |  +  Shift + 2     |
|  RCVR DSP ►      |  +  Shift + 3     |
|  RCVR SURR       |  +  Shift + 4     |
|  RCVR A.ST       |  +  Shift + 5     |
|  RCVR ◀ DSP      |  +  Shift + 6    |
|  RCVR SP A      |  +  Shift + 7 |
|  RCVR SP B     |  +  Shift + 8 |
|  RCVR Re-EQ    |  +  Shift + 9 |
|  RCVR Dimmer   |  +  Shift + 0 |
|  RCVR Display  |  INFO Info   |

| Original   | Replacement  |
|--|--|
|  RCVR Display |  Guide  |
|  RCVR Zone 2  |  Pre Ch |






| Original  | Replacement   | Original  | Replacement   |
|---|---|---|---|
|    |  Power   |      |  Subt  |
|    |  +  Shift + Power |      |  I<<   |
|    |  Back  |      |  Play  |
|    |  Options   |      |  >>I   |
|    |  Ch +  |      |  <<    |
|    |  Ch -  |      |  Stop  |
|    |  Up  |      |  >>    |
|    |  Left  |      |  Text  |
|    |  Ok  |      |  Pause |
|    |  Right   |      |  Eject |
|   |  Down   |  1  |  1    |
|  |  Vol +   |  2 |  2   |
|  |  Vol -   |  3 |  3   |
|  |  Mute  |  4 |  4   |
|  |  D. Menu   |  5 |  5   |
|  |  Menu  |  6 |  6   |
|  |  Format  |  7 |  7   |


















| Original   | Replacement   | Original | Replacement |
|--|---|----------|-------------|
|  8      |  8     |          |             |
|  9      |  9     |          |             |
|  0      |  0     |          |             |
|  +10    |  Guide |          |             |
|  Search |  TV/R  |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |





| Original  | Replacement   | Original  | Replacement   |
|---|---|---|---|
|    |  Power         |  |  3     |
|    |  Shift + Power |  |  4     |
|    |  Ch +          |  |  5     |
|    |  Vol +         |  |  6     |
|    |  Vol -         |  |  7     |
|    |  Mute          |  |  8     |
|    |  I<<           |  |  9     |
|    |  Play          |  |  0     |
|    |  >>I           |  |  Guide |
|    |  <<            |   |   |
|   |  Stop         |   |   |
|  |  >>          |   |   |
|  |  Text        |   |   |
|  |  Pause       |   |   |
|  |  Eject       |   |   |
|  |  1           |   |   |
|  |  2           |   |   |





| Original | Replacement   | Original | Replacement |
|----------|---------------|----------|-------------|
|          | Power         |          | 3           |
|          | Shift + Power |          | 4           |
|          | Vol +         |          | 5           |
|          | Vol -         |          | 6           |
|          | Mute          |          | 7           |
|          | I<<           |          | 8           |
|          | Play          |          | 9           |
|          | >>I           |          | 0           |
|          | <<            |          | Guide       |
|          | Stop          |          | Pre Ch      |
|          | >>            |          | Ok          |
|          | Text          |          |             |
|          | Rec           |          |             |
|          | Pause         |          |             |
|          | Eject         |          |             |
|          | 1             |          |             |
|          | 2             |          |             |

