







































































Original	Replacement	Original	Replacement
 Power	 Power	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Home	 Smart
 3	 3	 [G]	 Guide
 4	 4	 i	 Info
 5	 5	 ←	 Back
 6	 6	 Exit	 Exit
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Lang	 Dual	 OK	 Ok
 [≡]...	 Subt	 Netflix	 Shift + Media
 Vol+	 Vol +	 You Tube	 Shift + Smart
 Vol-	 Vol -	 Menu	 Menu
 Mute	 Mute	 Source	 AV
 Smart/Colors	 Media	 Red	 Red





Original		Replacement		Original		Replacement	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	>>		>>				
	Stop		Stop				
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Play		Play				
	Text		Text				

