







































































Original	Replacement	Original	Replacement
 Power	 Power	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Home	 Smart
 3	 3	 [G]	 Guide
 4	 4	 i	 Info
 5	 5	 ←	 Back
 6	 6	 EXIT	 Exit
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Lang	 Dual	 OK	 Ok
 [≡]...	 Subt	 Netflix	 Shift + Media
 Vol+	 Vol +	 You Tube	 Shift + Smart
 Vol-	 Vol -	 Menu	 Menu
 Mute	 Mute	 Source	 AV
 Smart/Colors	 Media	 Red	 Red





Original	Replacement	Original	Replacement
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 >>	 >>		
 Stop	 Stop		
 >>	 >>		
 Rec	 Rec		
 Pause	 Pause		
 Play	 Play		
 Text	 Text		

