




















































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	VOD		Smart
	IP		Shift + Smart
	USB		Media
	TXT		Text
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Back		Back
	EPG		Guide
	Vol+		Vol +
	Vol-		Vol -
	APPS		Shift + Media
	SAT		AV
	P+		Ch +
	P-		Ch -
	Recall		Pre Ch
	Info		Info
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Menu		Menu
	Exit		Exit
	Red		Red





Original	Replacement	Original	Replacement
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Fav	 + 	Shift + Pre Ch
	Subt		Subt
	Audio		Dual
	TV/Ra		TV/R
	Rec		Rec
	Find	 + 	Shift + TV/R
	Play/Pause		Play
	Play/Pause		Pause
	Stop		Stop
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>

