







































































Original	Replacement	Original	Replacement
	Slow		Right
	ShowView		Smart
	Power		Power
	Input		AV
	Display		Info
	P.STD		Format
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	Pre-CH		Pre Ch
	Menu		Menu
	V.Menu		D. Menu
	P +		Ch +
	P -		Ch -
	Vol +		Vol +
	Vol -		Vol -
	<< REW		<<
	Stop		Stop
	Play		Play
	>> FF		>>
	Rec		Rec
	Eject		Eject
	Pause / P/S		Pause
	TRK Up		>>I
	TRK Down		I<<



