






































































Original		Replacement		Original		Replacement	
	Power		Power		Setup		Options
	Open/Close		Eject		<< FR/SR		<<
	1		1		>> FF/SF		>>
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Sel		Ok
	7		7		I<<		I<<
	8		8		Display		Info
	9		9		>>I		>>I
	0		0		Title		List
	Clear		Exit		Menu		Menu
	PBC		Guide		Marker		TV/R
	Stop/Return		Stop		Angle		Red
	Play/Pause		Play		Subtitle		Subt
	>I</Step		Pause		Audio		Dual





Original	Replacement
 Zoom	 Shift + Eject
 3D Sound	 3D
 Repeat	 Text
 Program	 Sleep
 Shuffle	 Media
 Digest	 Yellow
 A-B	 Shift + Play
 Vol+	 Vol +
 Vol-	 Vol -

Original	Replacement

