

























































Original	Replacement	Original	Replacement
C/CH	 Sleep / Timer	6	 6
Digest	 Exit / Cancel / Clear	7	 7
Pbc	 Text / Goto	8	 8
Echo-	 +  Shift + CH- /	9	 9
Echo+	 +  Shift + CH+ /	+10	 Guide / EPG / -/-
Store	 Picture / Format	0	 0
Play	 Play / Slow	Record	 Rec / Rec Mode
Auto/Track	 Smart / List	Rewind	 << / Tune-
DVD/TV	 AV / Input / RDS	1	 1
Progr.	 TV/Radio /	F.Forward	 >> / Tune+
Slow Down	 CH- / Page-	Open/Close	 Eject / Surround
Slow Up	 CH+ / Page+	Setup	 Setup / OPT /
Repeat/1/All	 Green / APP / Repeat	Search	 Red / Netflix / Search
2	 2	Angle	 Info / Angle
3	 3	Lang	 Audio / Lang I/II
4	 4	Random	 Blue / Prime Video / Random
5	 5	Menu Up	 Up



Original	Replacement	Original	Replacement
Audio Off	 Mute / Dimmer	Volume-	 Vol-
Stop	 Stop / Hold	Top Menu	 D.Menu / Top
Pause	 Pause / Step / Freeze	Prev.	 I<< / Preset-
Subt.	 Subtitle / EQ		
Rep/A-B	 Yellow / YouTube / Repeat		
Title	 Sound / Title		
Zoom	 Zoom / Size		
Menu	 Menu / Home		
On/Off	 Power		
Display	 Display / Media		
Menu Left	 Left		
OK Enter	 OK		
Menu Right	 Right		
Return	 Back / Return		
Menu Down	 Down		
Volume+	 Vol+		
Next	 >>I / Preset+		

