























































Original	Replacement	Original	Replacement
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Display	 Shift + Info
Update	 3D	Menu Off	 Exit
Txt Stop	 Stop	Menu Down	 Down
Reveal	 List	Chan.Up	 Ch +
Info	 Info	Back	 Back
Return TV	 Shift + TV/R	Volume+	 Vol +
Subt.List	 Subt	Volume-	 Vol -
Sleep Timer	 Sleep	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Menu	 Menu	1	 1
Text	 Text	2	 2
Txt Expand	 Eject	3	 3
Menu Up	 Up	4	 4
TV/AV	 AV	5	 5
Menu Left	 Left	6	 6
OK Enter	 Ok	7	 7



Original	Replacement
3.*	 +  Shift + 3
Nicam/Mono	 +  Shift + Dual
8	 8
9	 9
Color- S.Std	 +  Shift + Format
Yellow	 Yellow
Guide -/-- 1.	 Guide
Off/Tim	 <<
On/Tim	 >>
Mix Scan	 +  Shift + Eject
Color+ P.Std	 +  Shift + Ch +
0/10	 0
Red	 Red
Contrast+	 +  Shift + Right
Green	 Green
Contrast-	 +  Shift + Left
2.Fav P/C 2.	 Pre Ch

Original	Replacement
Blue	 Blue
On Pip	 +  Shift + 1
Store Text	 +  Shift + Text
Store	 Options
Swap	 +  Shift + 2
Tone+	 +  Shift + Up
Game Coo	 Media
4.# 16:9	 Format
AV 2	 +  Shift + AV
Bright+ Mode	 Smart
Audio-	 +  Shift + Vol -
Audio+	 +  Shift + Vol +
Search	 TV/R

