






































































Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Subtitle		Subt		9		9
	Guide		Guide		0		0
	Freeze		Pause		ENT		Back
	FAV.CH		Pre Ch		Jump		Options
	Sleep		Sleep		Info		Info
	Mute		Mute		Input		AV
	I/II		Dual		CH+		Ch +
	P.Size		Shift + Format		CH-		Ch -
	[≡]/[≡]		Text		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Exit		Exit
	3		3		Menu		Menu
	4		4		OK		Ok
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right



