




Original	Replacement	Original	Replacement
	Power		Blue
	Mute		Up
	1		Down
	2		Right
	3		Left
	4		Ok
	5		SFI/EPG
	6		Recall/Exit
	7		Info
	8		Tv/Radio
	9		Menu
	0		Prog+
	A/B		Prog-
	Red		Vol+
	Green		Vol-
	Yellow		Hilfe
			TXT





Original		Replacement		Original		Replacement	
	Stop		Stop				
	EXT		AV				
	V		Smart				

