




































































Original		Replacement		Original		Replacement	
	Power		Power		Menu		Menu
	Mute		Mute		Source		AV
	1		1		Enter		Ok
	2		2		Up		Up
	3		3		Down		Down
	4		4		Left		Left
	5		5		Right		Right
	6		6		Exit		Exit
	7		7		Display		Shift + Info
	8		8		Vol+		Vol +
	9		9		Vol-		Vol -
	0		0		CH+		Ch +
	DTV/ATV		Info		CH-		Ch -
	Recall		Pre Ch		MTS		Shift + Sleep
	P.Mode		Shift + Format		Rec List		D. Menu
	S.Mode		Shift + Dual		FAV/List		Dual
	Sleep		Sleep		Rec		Rec



