







































































Original		Replacement		Original		Replacement	
	Power		Power		Home		Menu
	1		1		*		Options
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		OK		Ok
	7		7		Wheel Up		>>
	8		8		Wheel Down		<<
	9		9		Back		Back
	0		0		Guide		Guide
	List		List		Netflix		Smart
	Mute		Mute		Prime Video		Shift + Smart
	Vol+		Vol +		Red		Red
	Vol-		Vol -		Movies		Media
	CH+		Ch +		Green		Green
	CH-		Ch -		Yellow		Yellow



