







































































Original		Replacement		Original		Replacement	
	Power		Power		9		9
	Energy		Setup / OPT /		0		0
	Picture		Picture / Format		TTX		Text / Goto
	Sound		Sound / Title		Recall		Back / Return
	Mute		Mute / Dimmer		Menu		Menu / Home
	Audio		Audio / Lang I/II		Input		AV / Input / RDS
	Subtitle		Subtitle / EQ		Exit		Exit / Cancel / Clear
	16:9/4:3		Shift + Picture / Format		Info		Info / Angle
	Sleep		Sleep / Timer		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		OK
	5		5		Vol+		Vol+
	6		6		Vol-		Vol-
	7		7		Index/CH List		Smart / List
	8		8		Hold/EPG		Guide / EPG / -/-





	Original	Replacement	Original	Replacement
	Size/FAV List			Fav / Marker / PC
	Subpage/Play List			Display / Media
	CH+			CH+ / Page+
	CH-			CH- / Page-
	Play			Play / Slow
	Stop			Stop / Hold
	<<			<< / Tune-
	>>			>> / Tune+
	Tv Pause			Pause / Step / Freeze
	->/Goto			TV/Radio /
	<<			<< / Preset-
	>>			>> / Preset+
	Rec			Rec / Rec Mode
	Red			Red / Netflix / Search
	Green			Green / APP / Repeat
	Yellow			Yellow / YouTube / Repeat
	Blue			Blue / Prime Video / Random

