





















































Original	Replacement	Original	Replacement
	Mute		Mute / Dimmer
	Power		Power
	PP		Back / Return
	I-II		Audio / Lang I/II
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	--		Guide / EPG / -/--
	P<P		Fav / Marker / PC
	Menu		Menu / Home
	Info		Info / Angle
	Left		Left
	Up		Up
	P+		CH+ / Page+
	Right		Right
	Down		Down
	P-		CH- / Page-
	Vol-		Vol-
	Vol+		Vol+
	Red/Sound		Red / Netflix / Search
	Red/Sound		Sound / Title
	Green/Picture		Green / APP / Repeat
	Green/Picture		Picture / Format
	Yellow/Feature		Yellow / YouTube / Repeat
	Blue/Install		Blue / Prime Video / Random
	TV		TV/Radio /
	AV		AV / Input / RDS





	Original	Replacement	
	[≡]	Text / Goto	
	[/≡]	+ Shift + Text /	
	[≡o]	Sleep / Timer	
	[≡+]	Stop / Hold	
	[≡x]	Setup / OPT /	
	[≡♦]	Zoom / Size	
	[≡?]	Smart / List	
	[≡i]	Display / Media	

	Original	Replacement	

