




































Original	Replacement
 Power	 Power
 Sleep	 Sleep / Timer
 Mute	 Mute / Dimmer
 Mode	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 Eject/Nicam2	 Eject / Surround
 Eject/Nicam2	 Sound / Title
 4	 4
 5	 5
 6	 6
 TXT/MIX	 Text / Goto
 Play/Pause	 Play / Slow
 Play/Pause	 Pause / Step / Freeze
 7	 7
 8	 8

Original	Replacement
 9	 9
 Stop/Exit/Cancel	 Exit / Cancel / Clear
 Stop/Exit/Cancel	 Stop / Hold
 -/--	 Guide / EPG / -/--
 0	 0
 Back	 Back / Return
 SYS Menu	 Menu / Home
 Rec	 Rec / Rec Mode
 Up	 Up
 CH+	 CH+ / Page+
 DTV/Radio	 TV/Radio /
 Left	 Left
 Enter	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 CH-	 CH- / Page-





Original	Replacement
 Vol+	 Vol+
 Return	 Shift + Back / Return
 Menu DVD	 D.Menu / Top
 Setup	 Setup / OPT /
 Display	 Display / Media
 Search/FAV	 Shift + Red / Netflix /
 Search/FAV	 Fav / Marker / PC
 Slow/EPG	 Shift + Play /
 Slow/EPG	 Shift + Guide / EPG / --
 Language/Info	 Audio / Lang I/II
 Language/Info	 Info / Angle
 Zoom/List	 Zoom / Size
 Zoom/List	 Smart / List
 Red/Angle	 Red / Netflix / Search
 Red/Angle	 Shift + Info / Angle
 Green/Program	 Green / APP / Repeat
 Green/Program	 Shift + TV/Radio / Program

Original	Replacement
 Yellow/Repeat	 Shift + Green / APP /
 Yellow/Repeat	 Yellow / YouTube / Repeat
 Blue/A-B	 Blue / Prime Video / Random
 Blue/A-B	 Shift + Yellow / YouTube /
 <</Hold	 Shift + Stop /
 <</Hold	 << / Tune-
 >>/Index	 >> / Tune+
 I<</Size	 I<< / Preset-
 I<</Size	 Shift + Zoom /
 >>I/Reveal	 >>I / Preset+
 Subtitle	 Subtitle / EQ
 Title/Subpage	 Shift + Sound / Title
 FAV-	 Shift + Down
 FAV+	 Shift + Up

