





















| Original | Replacement | Original | Replacement |
|---|---|--|---|
|  Power |  Power |  Mute |  Mute |
|  1 |  1 |  Back |  Back |
|  2 |  2 |  CH+ |  Ch + |
|  3 |  3 |  CH- |  Ch - |
|  4 |  4 |  EPG |  Guide |
|  5 |  5 |  Menu |  Menu |
|  6 |  6 |  Up |  Up |
|  7 |  7 |  Left |  Left |
|  8 |  8 |  OK |  Ok |
|  9 |  9 |  Right |  Right |
|  0 |  0 |  Down |  Down |
|  TV/RAD / AV |  TV/R |  i |  Info |
|  TV/RAD / AV |  AV |  Exit |  Exit |
|  FAV / -/-- |  Pre Ch |  Red / << |  Red |
|  FAV / -/-- |  Shift + Guide |  Red / << |  << |
|  Vol+ |  Vol + |  Green / Play |  Green |
|  Vol- |  Vol - |  Green / Play |  Play |



