



	Original	Replacement		Original	Replacement
	Power		Power		Ch.List
	Source		AV		P +
	1		1		P -
	2		2		Media.P
	3		3		Menu
	4		4		Guide
	5		5		Tools
	6		6		Info
	7		7		Up
	8		8		Right
	9		9		Down
	0		0		Left
	TTX/MIX		Text		Enter
	PRE-CH		Pre Ch		Return
	Vol+		Vol +		Exit
	Vol-		Vol -		Red
	Mute		Mute		Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	P.Mode	 + 	Shift + Format		
	Dual I/II		Dual		
	3D		3D		
	AD	 + 	Shift + Subt		
	P.Size		Format		
	Subt.		Subt		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

