





























































| Original  |                  | Replacement   |        | Original  |           | Replacement   |       |
|---|------------------|---|--------|---|-----------|---|-------|
|    | On/Standby       |    | Power  |    | Disc CD 1 |    | 1     |
|    | Vol+             |    | Vol +  |    | Disc CD 2 |    | 2     |
|    | Vol-             |    | Vol -  |    | Disc CD 3 |    | 3     |
|    | X-Bass/Equalizer |    | Smart  |    | Disc Skip |    | Media |
|    | Video/AUX        |    | Red    |    | I<</<< CD |    | I<<   |
|    | Tape (1<->2)     |    | Blue   |    | >>/>>I CD |    | >>I   |
|    | Tuner(Band)      |    | Green  |    | Stop CD   |    | Stop  |
|    | CD               |    | Yellow |    | Play CD   |    | Play  |
|    | Rec/Pause Tape 2 |    | Rec    |    | Memory CD |    | 3D    |
|   | << Tape 2        |   | <<     |   | Clear     |   | Exit  |
|  | >> Tape 2        |  | >>     |  | Random    |  | TV/R  |
|  | Play Tape 2      |  | Left   |  | Pause CD  |  | Pause |
|  | Play Tape 1      |  | Right  |   |           |   |       |
|  | Stop Tape        |  | Ok     |   |           |   |       |
|  | Tuner Preset Up  |  | Ch +   |   |           |   |       |
|  | Tuner Preset     |  | Ch -   |   |           |   |       |
|  | PTY TI           |  | Back   |   |           |   |       |

