
























































Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow / YouTube / Repeat
 Source	 AV / Input / RDS	 Menu	 Menu / Home
 Picture	 Picture / Format	 0	 0
 Sound	 Sound / Title	 Exit	 Exit / Cancel / Clear
 Still	 Pause / Step / Freeze	 Blue	 Blue / Prime Video / Random
 Mute	 Mute / Dimmer	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 OK
 3	 3	 Right	 Right
 Red	 Red / Netflix / Search	 Down	 Down
 4	 4	 CH -	 CH- / Page-
 5	 5	 CH +	 CH+ / Page+
 6	 6	 Vol -	 Vol-
 Green	 Green / APP / Repeat	 Vol +	 Vol+
 7	 7	 Guide / Size	 Guide / EPG / -/--
 8	 8	 Index / Subtitle	 Subtitle / EQ
 9	 9	 Sleep	 Sleep / Timer

Original	Replacement	Original	Replacement
 Power	 DIMMER MUTE	 SHIFT	 TV
 Source	 DVD	 SAT	 AUX
 Picture	 SLOW	 STEP - FREEZE	 HOLD
 Sound	 TUNE -	 TUNE +	 PRESET -
 Still	 PRESET +	 TITLE	 LANG
 Mute	 EQ	 SURROUND	 SOUND
 1	 AUDIO	 SUBTITLE	 SIZE
 2	 TIMER	 PROGRAM	 PICTURE
 3	 TV RADIO	 RDS	 ZOOM
 Red	 AV INPUT	 D.MENU	 TOP MENU
 4	 HOME	 SETUP	 OPT-TOOLS
 5	 ANGLE	 TEXT	 GOTO
 6	 MENU	 INFO	 HOME
 7	 OK	 RETURN	 BACK
 8	 EXIT	 CLEAR	 CANCEL
 9	 LIST	 SMART	 MEDIA
 Green	 DISPLAY	 CH PAGE +	 VOL +
 Yellow	 TV	 DVD	 CD - STB
 Menu	 VIDEO	 TAPE	 TUNER
 0	 AUX - HDD	 USB	 BLUETOOTH
 Exit	SEARCH	REPEAT	REPEAT A-B
 Blue	APP	YouTube	Prime Video
 Up	RANDOM	Mandis SHOP	www.mandis.tv



