







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Input		AV
	TV		TV/R
	Quick		Media
	List		Smart
	List		List
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	AD		Shift + Subt
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Recall		Pre Ch
	Guide		Guide
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9



