








































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	EQ		Subtitle / EQ
	1		1
	2		2
	3		3
	VFD		Blue / Prime Video / Random
	4		4
	5		5
	6		6
	L/R		Red / Netflix / Search
	7		7
	8		8
	9		9
	P/N		Yellow / YouTube / Repeat
	Repeat		Green / APP / Repeat
	0/10		0
	10+		Guide / EPG / -/-
	Zoom		Zoom / Size
	TV Mode		Shift + 1
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	<<		<< / Tune-
	>>		>> / Tune+
	USB/Card		Shift + 8
	Up		Up
	Menu		Menu / Home
	Left		Left
	Enter		OK
	Right		Right
	Clock		Sleep / Timer





Original	Sustituto
 Down	 Down
 Setup	 Setup / OPT /
 Echo-	 CH- / Page-
 Echo+	 CH+ / Page+
 Mic Vol-	 Shift + Vol-
 Mic Vol+	 Shift + Vol+
 Mic On/Off	 Smart / List
 Treb+	 Shift + Up
 Bass+	 Shift + CH+ /
 Vol+	 Vol+
 Input	 AV / Input / RDS
 Treb-	 Shift + Down
 Bass-	 Shift + CH- /
 Vol-	 Vol-

Original	Sustituto

